


Tools Required




⚠ Before starting switch OFF Power Line/Power Supply
Installation should be done only by trained technical team

LIMITLESS – Neon Flex


LV12



LV16




LV25




Vertical bending


LH12



LH16




L3D



Horizontal bending

3D bending


Warning




Must be followed
for each model

Operations


- 1 Mark the wall using aluminium profile as guide




- 2 Drill the wall where there are marks and fix the profile using screws



- 3 Fix the flexible light body inside the aluminium profile



- 4 Connect it to power supply cable and ensure it's all well fixed




- 5 Recheck the connection and confirm that it is connected properly.
Switch On the power supply.

Tools Required



⚠ Before starting switch OFF Power Line/Power Supply
Installation should be done only by trained technical team

A Mono colour driver connection



B RGBW driver connection

