

Tools Required




Before starting switch OFF Power Line/Power Supply

Installation should be done only by trained technical team


Guide applicable only to the following products

TAP Series - Projector


TAP30




TAP60



TAP75



TAP12




TAP30 | 2 Watt

TAP60 | 6 Watt


TAP75 | 12 Watt

TAP12 | 24 Watt


- ① Fix the bracket to the ground using screw or spyke (not included in the package)



- ② Adjust the projector orientation and tighten the side screws



- ③ Connect the projector to power supply cable using IP68 connector (to be order separately)



- ④ Recheck the connection and confirm that it is connected properly.
Switch On the power supply.


Tools Required



Before starting switch OFF Power Line/Power Supply
Installation should be done only by trained technical team
Guide applicable only to the following products


TAP Series - Surface

TAPS60




TAPS60 | 6 Watt

TAPS75




TAPS75 | 12 Watt

TAPS12




TAPS12 | 24 Watt


- ① Using the base bracket holes as a guide mark the ceiling




- ② Drill holes on ceiling where there are marks and fix the bracket using screws




- ③ Lock the power supply cable using provided accessories in order to guarantee IP protection




- ④ Connect the driver to power supply cable and ground cable to insulated terminal ring



- ⑤ Fix the light body to the bracket using hex key



- ⑥ Ensure the product is properly fixed



- ⑦ Recheck the connection and confirm that it is connected properly.
Switch On the power supply.


Tools Required




Before starting switch OFF Power Line/Power Supply
 Installation should be done only by trained technical team
 Guide applicable only to the following products

TAP Series - Wall mounted Mono emission


TAPWM60



TAPWM75



TAPWM12




TAPWM60 | 6 Watt

TAPWM75 | 12 Watt


TAPWM12 | 18 Watt

TAP Series - Wall mounted Double emission


TAPWD60



TAPWD75



TAPWD12




TAPWD60 | 4+4 Watt

TAPWD75 | 8+8 Watt


TAPWD12 | 12+12 Watt

Operations


- ① Using the bracket holes as a guide mark the wall




- ② Drill holes on ceiling where there are marks and fix the bracket using screws



- ③ Connect the product to power supply cable and fix it to the bracket using screws



- ④ Ensure the product is properly fixed



- ⑤ Recheck the connection and confirm that it is connected properly.
Switch On the power supply.